

SAMSON HIRE

1800 77 88 99

www.samsonhire.com.au | info@samsonhire.com.au

Changing the message on your electronic advertising sign.

The office will advise which type of sign you have been allocated, and the username and password for D or B Types or O Type.

B Type:

- Click www.samsonhire.com.au/client-area/ (Save in favourites for easy access)
- Click 'B Type' and use the following login details
- Username: Password:
- Double click on your sign
- Click 'New File' on the top menu
- Go to the 'Text Overlay' box and type your desired message
- You can add more frames by clicking the single right facing arrow above your message preview
- When finished go to 'File'
- Click 'Save' then 'Upload'

Need assistance?

Contact one of our friendly customer support team members on 1800 77 88 99